Installation of Cartasite ROVR dT9 J1939 Device for use with A**z**uga E**L**D .

Note: The first few instructions below is for an initial connection to the Cartasite ROVR dT9 device. If you have already paired the Cartasite ROVR dT9 device to your phone or tablet, proceed to Step 4.

Step 1 – Connect the device using Cartasite ROVR dT9 to J1939 Adapter Cable.



- 1. The device plugs directly into the J1939 adapter cable. The cable then plugs into the vehicle's J1939 socket. The device does not need special prerequisites or installation from authorized personnel.
- 2. After the device is plugged into the socket, the yellow, blue and red LED starts blinking with 1Hz rate along with a beep which can be heard once on the first sound, twice on the second sound and a long beep on the third sound. This means the device is powered and operational.

Step 2 – Enable Bluetooth functionality on your Android phone or tablet.

- 1 From the main screen, Go to Settings.
- . Tap Bluetooth (under connections).
- 2 Tap the switch for "OFF" to "ON" position to turn on Bluetooth and put your Android phone or
- . tablet into pairing mode.
- 3

Step 3 – Pair your Android phone or tablet with the Cartasite device.

- Upon completion of Step 2 above, the Android phone or tablet should display a list of available Bluetooth devices. In case the list is not available, tap on the "Scan for Devices" or "Search" button.
- After a 5-10 second delay, the "AX7_BT40" device should appear on the list of the Available Devices. If the device is not available in the list, make sure you are in close proximity to the Cartasite ROVR dT9 device (less than 32 feet or 10meters), and the Cartasite ROVR dT9 device is powered on (see Step 1 above).
- 3. Tap on the "AX7_BT40" device, then the device goes into pairing mode and the "Pairing..." message is displayed.

° G			* 🔋 91	% 8:27 AM	
Settings	SEARCH	Blu	etooth	SCAN	
Connections		On		-	
🥱 Wi-Fi		You	Your device (Galaxy Tab A - M) is currently visible to nearby devices.		
Bluetooth		Pair	ed devices		
Airplane mode			MOBILE18 Paired	\$	
Data usage			DESKTOP-4E1UUTV Paired	۵	
More connection	settings		LMU_4843001786 Paired	\$	
Device		_	SHERLOCK		
o Sounds and notif	ications		Paired	\$	
🚯 Display			WQ-81A160480001 Paired	\$	
		Avai	lable devices		
Motions and ges	tures	R	AX7_BT40		

4. By default the Cartasite device does not require any PIN configurations. After a few seconds, the pairing process should complete, and "AX7_BT40" will appear in the list of "Paired Devices."

ਛੇ Settings	SEARCH	Blue	etooth	≉ 92%∎	STOP
Connections		On		U)	
🤝 Wi-Fi		Your device (Galaxy Tab A - M) is currently visible t		isible to nearby devic	es
Bluetooth			ed devices	sible to hearby device	
Airplane mode		ନ୍ଥ	AX7_BT40 Paired		\$
📶 Data usage			DESKTOP-4E1UUTV Paired		\$
More connection	settings		LMU_4843001786 Paired		\$
Device Sounds and notifie	cations		MOBILE18 Paired		\$
🐻 Display			SHERLOCK Paired		\$
Motions and gest	ures		WQ-81A160480001 Paired		\$
		Avai	lable devices		

5. You can rename the paired "AX7_BT40" device into something more meaningful, like "Truck 1" if you prefer. Tap on the blue gear button () to "Rename" or "Unpair" the device.

Step 4 – Use the Azuga ELD Mobile App with the paired Cartasite ROVR dT9 device.

Open Azuga ELD app (or Branded App)
 Tap on the VBUS icon (or Tap the Connect button on the Connection bar)

9		🛇 ପ୍ରି 😤 22% 🖺 8:38 AM
		M 🛱 C 🕂
		Connect X
	Sherlock Holmes IX	ROADSIDE INSPECTION
OffDuty •	Connect to Vehicle Do you want to connect to vehicle TRU-001?	OPTIONS
	MANUAL CONNECTION CANCEL CONNECT	LOGS
Time Remaining	RECAP	
		DVIR
00.00	START BREAK	SHIFT/CYCLE

3.At this point, 2 options were present in order to establish a connection to the VBUS device: Manual Connection and Auto Connection.

a.Manual Connection

- o Tap on the Manual Connection button
- o Select VBUS Device Cartasite ROVR dT9 J1939

e ³		🛇 ପ୍ରି 🌹 22% 🖺 8:39 AM
		📮 C 🕣
		Connect
	Supported VBUS Devices O CalAmp LMU4230	ADSIDE INSPECTION
OffDuty -	 Cartasite ROVR dT9 J1939 Cartasite ROVR dT9 OBD2 Digi WVA 	OPTIONS
Time Remaining	 ELM327 Geometris 	LOGS
00:00	MGNOBD BACK NE	DVIR
	START BREAK	SHIFT/CYCLE

- Tap on the Next button
- It will then display the list of available devices along with the following buttons:

a.Back button - tapping this button will go back to the previous Supported VBUS devices dialog

b.Pair button - tapping this button will open the Android Device Settings > Bluetooth screen, to be able to pair devices.

c.Connect button - Select 'AX7_BT40' from the device list then tap the Connect button.

9 3		🛇 🕸 🛱 🛜 59% 🖥 5:00 PM	
\equiv Hours of Service		፼ C €]	
		Connect X	
	Select Cartasite ROVR dT9 J1939 Bluetooth Classic Device	ADSIDE INSPECTION	
	O WQ-81A160480001 (10:80:01:77:30:98)		
	AX7_BT40 (8C:DE:52:9A:B1:E7)	OPTIONS	
OffDuty -	O SJ5-VISTRACKS (E8:3A:12:97:99:03)		
	OontZ Angle (7C:2E:56:2B:0F:A6)	LOGS	
Time Remaining	O Jeprox (F0:79:59:B2:29:3D)	1000	
	BACK PAIR CONNECT	DVIR	
	START BREAK	SHIFT/CYCLE	

 It will then display the VBUS Progress dialog upon establishing a connection to the selected VBUS device along with a 'Stop Connection' and 'Ok' buttons

a.Tap 'Stop Connection' button to stop establishing VBUS connection. b.Tap OK button to hide the VBUS Progress dialog while establishing VBUS connection.

₽ w D %	🗣 🕸 🎅 🕄 33% 🛢 2:02 PM
	D 🔅 C 🗲
	Connect X
Shehock Holmes IX	E INSPECTION
VBUS Progress	TIONS
OffDuty Establishing connection to Cartasite ROVR dT9 J1939	
STOP CONNECTION OK	.0GS
Time Remaining RECAP	DVIR
START BREAK	T/CYCLE

If the VBUS connection results to an error (given the following situations below), an error dialog will display.

■VBUS Connection Error i.Interrupted Internet Connection ii.VBUS Power Failure

D %	🛇 🕸 🗑 🔋 32% 🛢 2:04 PM	
	D 🗳 C 🕣	
	Connect X	
B Sherlock Holmes IX	ROADSIDE INSPECTION	
VBUS Data Error	TIONS	
OffDuty Vbus timeout error to establish connection		
RETRY	OGS	
Time Remaining RECAP	DVIR	
START BREAK	SHIFT/CYCLE	

Note: The app will automatically disconnect from the device after attempting to connect for 1 minute and 30 seconds without receiving any data from the VBUS device.

- After a successful VBUS connection, You should hear a tone letting you know that device is now connected.
- O To check if you are connected, go to the Android Notification Bar and you should see the following message.



• Check also that the VBUS indicator is now changed to a WiFi icon (during successful connection)

The device and the application are now connected.

- b. Auto Connection
 - \bigcirc Tap on the Connect button
 - The VBUS Progress dialog will then display
 - Upon establishing a connection to the VBUS device, You should hear a tone letting you know that device is now connected.
 - Prerequisites to successfully perform Auto Connection
 - Create a Preconfigured device in the Portal's Equipment Management

Page or in the App's Manage Vehicles/Trailers screen

 \bigcirc Set the ELD Configurations